


PLAST FORDELER TIL GULVVARMESYSTEM		2 kredse	3 kredse	4 kredse	5 kredse	6 kredse	7 kredse	8 kredse	9 kredse	10 kredse	11 kredse	12 kredse	
1	BD-nr.												
	Basismodul inkl. udlufter, aftap og 20mm fittings. 2 afg.	04 6100.102	1	1	1	1	1	1	1	1	1	1	
	Udvidelsesmodul, inkl. 20mm fittings	04 6100.808		1	2	3	4	5	6	7	8	9	10
TRÅDLØS STYRING 868 MHZ													
2	BD-nr.												
	Telestat 230V	04 6125.119	2	3	4	5	6	7	8	9	10	11	12
	Rumtermostat u/gulvføler	04 6125.105	2	3	4	5	6	7	8	9	10	11	12
	Styremodul - 2 zoner	04 6125.202	1										
	Styremodul - 6 zoner	04 6125.206		1	1	1	1						
Styremodul - 12 zoner	04 6125.212						1	1	1	1	1	1	
SHUNT													
3	BD-nr.												
	Parallelshunt - Alpha2 pumpe	04 6122.120	1	1	1	1	1	1	1	1	1	1	
FLEXUNIT													
4	BD-nr.												
	Flexunit - holder styr på rørene	40 2021.100	1	1	1	1	1	1	1	1	1	1	
ALTERNATIVE RUMTERMOSTATER													
	BD-nr.												
	Rumtermostat m/gulvføler	04 6125.106											
	Rumtermostat u/gulvføler	04 6125.100											
	Rumtermostat m/gulvføler	04 6125.101											
	Digital rumtermostat	04 6125.090											
	Rumtermostat u/gulvføler	04 6125.060											
	Rumtermostat m/gulvføler	04 6125.080											



04 6100.102




04 6100.808



04 6125.119

04 6125.105/  
04 6125.106

04 6125.202



04 6125.206





04 6125.212



04 6122.120

04 6125.100/  
04 6125.101

04 6125.090

04 6125.060/  
04 6125.080

40 2021 100